

# Monitoring the PCFS

For LBA disk-based recording the PCFS is controlling the antenna and the power meters are being monitored by xplot. The VCO output is not being recorded, all the data are being recorded independently by the LBA recorder in the block-0 rack. So the most important thing to check with the PCFS is that the time is correct and that the source commands are being received at the NMC.

From:

<http://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<http://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/tidnotes/monitoringpcfs>

Last update: **2015/12/18 16:39**

