

- Kernel TCP Congestion (BIC or CTCP)
- Correct NIC interfaces/VLAN selected
- TSO turned off
- Max TCP buffer large enough
- MTU set appropriately
- JIVE sending large enough TCP window size
- ATCA reference position (caobs AND correlator)

ATCA 203.0.88.211 12 MB TCP buffer Mopra 192.42.120.163 16 MB TCP buffer

From:

<https://www.atnf.csiro.au/people/atzioumi/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<https://www.atnf.csiro.au/people/atzioumi/vlbi/dokuwiki/doku.php/lbaops/expres-checklist>

Last update: **2015/12/18 16:38**

