

- Kernel TCP Congestion (BIC or CTCP)
- TSO turned off
- Max TCP buffer large enough
- MTU set appropriately
- JIVE sending large enough TCP window size
- ATCA reference position (caobs AND correlator)

From:

<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/expres-checklist?rev=1188219942> 

Last update: **2015/12/18 16:38**