

vc032 Setup:

Description	Fringe Test for v190i
Antennas	Pa-At-Mp-Ho
Start	207 22:00:00
Stop	207 23:00:00
PI	LBA observers
Channel 1	DAS #1 IFP#1-L0 1634 - 1650 MHz USB RCP
Channel 2	DAS #1 IFP#1-HI 1650 - 1666 MHz USB RCP
Channel 3	DAS #1 IFP#2-L0 1634 - 1650 MHz USB LCP
Channel 4	DAS #1 IFP#2-HI 1650 - 1666 MHz USB LCP
Channel 5	DAS #2 IFP#1-L0 1666 - 1682 MHz USB RCP
Channel 6	DAS #2 IFP#1-HI 1682 - 1698 MHz USB RCP
Channel 7	DAS #2 IFP#2-L0 1666 - 1682 MHz USB LCP
Channel 8	DAS #2 IFP#2-HI 1682 - 1698 MHz USB LCP
DAS 1 Skyfreq	1650.00 MHz
DAS 2 Skyfreq	1682.00 MHz
Bandwidth	16 MHz
DAS Mode	vsop.pro (telescope)

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/fringe-checks/vc032>

Comments:

Follow setup for v190i


Observing comments for each antenna:

[Pa](#) [At](#) [Mp](#) [Ho](#)

Observing Logs

[Parkes onsource flagging](#)

[Mopra onsource flagging](#)



From:

<http://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<http://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbajul2007/vc032>



Last update: **2015/12/18 16:38**