

vt02f8 Setup:

Description	Real-time fringe-check for v195a
Antennas	At-Mp-Ho-Pa
Start	73 13:00:00
Stop	73 14:05:00
PI	LBA fringe-check
Channel 1	IFP#1 1665 - 1669 MHz USB RCP
Channel 2	IFP#2 1665 - 1669 MHz USB LCP
Sky Center Freq	1667 MHz
Bandwidth	4 MHz
Recorder	Disk through S2
DAS Mode	at4s.pro (telescope)
S2 Mode	8x4-2
Swap Cable	in

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt02/vt02f/vt02f8>

Comments:

Connect DAS to S2, VSIC to S2 via BG2 adapter

Swap cable must be installed

Record on /data/internal

Use RecordMode "Channel 1,2" in disko or (-c oox in vsib_record)

On S2 type "uic feedthru on"

From:

<http://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<http://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamar2006/vt02f8>

Last update: **2015/12/18 16:38**

