

VT002b1 Setup:\\

Antennas	Pa-At-Mp-Ho-Cd
Start	68 17:30:00
Stop	69 17:26:00
Channel 1	8417 - 8433 MHz USB RCP
Channel 2	8417 - 8433 MHz USB LCP
Bandwidth	16 MHz
Recorder	Disk
S2 Mode	32x4-2
DAS Mode	at16s.pro
Buggary Cable	in

\\
--\\

Comments:\\

Setup and fringe checks. Please email or phone Chris at Narrabri to coordinate the fringe test. Let him know an estimate of when you will be on source and when you actually are. We will run fringe test through s2 to minimize changes to the system.

From:
<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:
<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamarch2005/vt002b1?rev=1110020167>

Last update: **2015/12/18 16:38**

