

VT002b2 Setup:

Antennas	Mp-At-Ho-Pa-Ti
Start	71 05:00:00
Stop	71 06:45:00
Channel 1	1634 - 1650 MHz USB LCP
Channel 2	1650 - 1666 MHz USB LCP
Bandwidth	16 MHz
Recorder	Disk only
S2 Mode	32x4-2
DAS Mode	vsop.pro
Buggary Cable	out

Comments:

Setup and fringe checks

Please phone chris when you are on source. To record data use, for example, > vsib_record -t 7200s -c oox -o vt002b2_Mp

Remember on the S2 to turn "uic feedthru on"

From:

<http://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<http://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamarch2005/vt002b2>

Last update: **2015/12/18 16:38**

