

v131ax Setup:\\

Antennas	Pa-At-Mp-Ho-Cd
Start	137 03:00:00
Stop	138 02:56:00
Channel 1	8417 - 8433 MHz USB RCP
Channel 2	8417 - 8433 MHz USB LCP
Bandwidth	16 MHz
Recorder	S2
S2 Mode	32x4-2
DAS Mode	at16s.pro
Buggary Cable	in
Tape Change	137 08:56:00
Tape Change	137 14:56:00
Tape Change	137 20:56:00

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/v131/v131ax>

--

Comments:\\

Alternatively use S2 mode 32a4-2 without buggary cable.
Either edit .skd file before running drudg, or edit .prc file after running drudge

From: <https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link: <https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamay2005/v131ax?rev=1114757479>

Last update: **2015/12/18 16:38**

