

vt03a1 Setup:

Antennas	At-Mp-Pa-Ho-Bart(NZ)
Start	132 22:00:00
Stop	133 01:00:00
PI	Gulyaev/Natusch/Tingay
Channel 1	1650 - 1666 MHz USB RCP
Channel 2	1650 - 1666 MHz USB LCP
Bandwidth	16 MHz
Recorder	disk
S2 Mode	N/A
DAS Mode	at16s.pro
Buggary Cable	out

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>

Comments:

ATCA and Mopra telescope schedules in place

Parkes .psn schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>

Hobart VEX schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>

To set this experiment up:

- 1) Connect DAS output to VSIC directly (no buggery cable), and then to recorder;
 - 2) Change to a new directory;
 - 3) Start recording: `vsib_record -t 3h -s 2005-05-12T22:00:00 -o vt03a1_<antenna>`
-

Fringes: <http://pentane.ssi.swin.edu.au/~cwest/corr/vt03a1/>

From:
<http://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:
<http://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamay2005/vt03a1>

Last update: **2015/12/18 16:38**

