

vt03a2 Setup:\\

Antennas	At-Mp-Pa-Ho-Nz
Start	136 22:00:00
Stop	137 01:00:00
PI	Steven Tingay
Channel 1	1650 - 1666 MHz USB RCP
Channel 2	1650 - 1666 MHz USB LCP
S2	32x4-2 (uic feedthru on)
Bandwidth	16 MHz
Recorder	Disk direct from DAS
DAS Mode	at16s.pro

\
 Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a2>\
 ---\
 \
 \

Comments:\\

\
 \
 ATCA and Mopra telescope schedules in place\
 \
 Parkes .psn schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>\
 \
 Hobart VEX schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>\
 \
 To set this experiment up:\
 \
 1) Connect DAS output to VSIC directly (no buggery cable), and then to recorder;\
 \
 2) uic feedthru on - S2

2) Change to a new directory;\
 \
 3) Start recording: vsib_record -t 3h -s 2005-05-16T22:00:00 -o vt03a1_<antenna>\
 \

From:
<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:
<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamay2005/vt03a2?rev=1116278030>

Last update: **2015/12/18 16:38**

