

vt03a2 Setup:\\

Antennas	At-Mp-Pa-Ho-Nz
Start	136 22:00:00
Stop	137 01:00:00
PI	Steven Tingay
Channel 1	1650 - 1666 MHz USB RCP
Channel 2	1650 - 1666 MHz USB LCP
S2	N/A
Bandwidth	16 MHz
Recorder	Disk direct from DAS
DAS Mode	at16s.pro

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a2>

--

Comments:\\

ATCA and Mopra telescope schedules in place

Parkes .psn schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>

Hobart VEX schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a1>

To set this experiment up:

- 1) Connect DAS output to VSIC directly (no buggery cable), and then to recorder;
- 2) uic feedthru on - S2 \ 2) Change to a new directory;
- 3) Start recording: vsib_record -t 3h -s 2005-05-16T22:00:00 -o vt03a1_<antenna>

From:
<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:
<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamay2005/vt03a2?rev=1116278059>

Last update: **2015/12/18 16:38**

