

## vt03a3 Setup:

<b>Antennas</b>	At-Mp-Pa-Ho-Nz
<b>Start</b>	139 22:00:00
<b>Stop</b>	140 00:00:00
<b>PI</b>	Steven Tingay
<b>Channel 1</b>	1650 - 1666 MHz USB RCP
<b>Channel 2</b>	1650 - 1666 MHz USB LCP
<b>Bandwidth</b>	16 MHz
<b>Recorder</b>	Disk (DAS direct to VSIC)
<b>DAS Mode</b>	<a href="http://at16s.pro">at16s.pro</a>

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a3>

---

## Comments:

ATCA and Mopra telescope schedules in place

Parkes .psn schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a3>

Hobart VEX schedule at <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt03/vt03a3>

To set this experiment up:

- 1) Connect DAS output to VSIC directly (no buggery cable), and then to recorder;
- 2) Change to a new directory;
- 3) Start recording: `vsib_record -t 2h -s 2005-05-19T22:00:00 -o vt03a3_<antenna>`

From:  
<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:  
<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamay2005/vt03a3>

Last update: **2015/12/18 16:38**

