

# v131be Setup:\

<b>Description</b>	Fringe Finding for Astrometry Project
<b>Antennas</b>	At-Mp-Cd
<b>Start</b>	318 16:00:00
<b>Stop</b>	319 06:00:00
<b>PI</b>	Roopesh Ojha
<b>Channel 1</b>	IFP#1 8417 - 8433 MHz USB RCP
<b>Channel 2</b>	IFP#2 8417 - 8433 MHz USB LCP
<b>Skyfreq</b>	8425 MHz
<b>Bandwidth</b>	16 MHz
<b>Recorder</b>	S2
<b>DAS Mode</b>	at16s.pro ( <a href="#">telescope</a> )
<b>S2 Mode</b>	32a4-2
<b>Swap Cable</b>	out
<b>Tape Change</b>	318 21:56:00
<b>Tape Change</b>	319 03:56:00

\ Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/v131/v131be> \ --\ \

## Comments:\

\ Plug S2 into DAS, then VSIC into back of S2\ \ S2 swap cable should NOT be used\ \ Record on /data/internal\ \

## Observing comments for each antenna:\

[At](#) [Mp](#) [Cd](#)

\ --\

## Observing Logs\

[Parkes onsource flagging](#)

From: <https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link: <https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbanov2006/v131be?rev=1163838330>

Last update: **2015/12/18 16:38**