

DAS GUI will not start\\

Check DAS module has loaded. E.g:

```
cavsi1:~> lsmod | grep ds  
ds 10356 4
```

If not try:

```
su  
/etc/init.d/ds
```

DAS gives communications error in purple popup window on first config after power cycle\\

Try a second time

DAS shows no flashing "rx" and "busy" lights on front panel of the dataset module.\\

Bandpass on those channels will look crap.\\ \ Force the data set to load. Chris knows how.

From:
<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:
<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/dashints?rev=1212689543>

Last update: **2015/12/18 16:38**

