

## vt02fc Setup:

|                    |   |
|--------------------|---|
| <b>Description</b> | Fringe test for v185b                   |
| <b>Antennas</b>    | At-Mp-Ho-Cd-Pa                          |
| <b>Start</b>       | 82 09:00:00                             |
| <b>Stop</b>        | 82 11:00:00                             |
| <b>PI</b>          | LBA observers                           |
| <b>Channel 1</b>   | 2272 - 2288 MHz USB RCP                 |
| <b>Channel 2</b>   | 2272 - 2288 MHz USB LCP                 |
| <b>Bandwidth</b>   | 16 MHz                                  |
| <b>Recorder</b>    | Disk through S2                         |
| <b>DAS Mode</b>    | at16s.pro ( <a href="#">telescope</a> ) |
| <b>S2 Mode</b>     | 32a4-2                                  |
| <b>Swap Cable</b>  | out                                     |

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/vt02/vt02f/vt02fc>

---

## Comments:

Swap cable should NOT be used

Record on /data/internal

Use RecordMode "Channel 1,3" in disko or (-c oxox in vsib\_record)

On S2 type "uic feedthru on" if not already enabled

From:

<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbamar2006/vt02fc?rev=1142990111>

Last update: **2015/12/18 16:38**

