

# vc010 Setup:

<b>Description</b>	real-time fringe-check for v192a
<b>Antennas</b>	At-Pa
<b>Start</b>	317 19:15:00
<b>Stop</b>	317 20:20:00
<b>PI</b>	LBA fringe-check
<b>Channel 1</b>	DAS #1 IFP#1-L0 1384 - 1400 MHz USB RCP
<b>Channel 2</b>	DAS #1 IFP#1-HI 1400 - 1416 MHz USB RCP
<b>Channel 3</b>	DAS #1 IFP#2-L0 1384 - 1400 MHz USB LCP
<b>Channel 4</b>	DAS #1 IFP#2-HI 1400 - 1416 MHz USB LCP
<b>Channel 5</b>	DAS #2 IFP#1-L0 1416 - 1432 MHz USB RCP
<b>Channel 6</b>	DAS #2 IFP#1-HI 1432 - 1448 MHz USB RCP
<b>Channel 7</b>	DAS #2 IFP#2-L0 1416 - 1432 MHz USB LCP
<b>Channel 8</b>	DAS #2 IFP#2-HI 1432 - 1448 MHz USB LCP
<b>DAS 1 Skyfreq</b>	1400.00
<b>DAS 2 Skyfreq</b>	1432.00
<b>Bandwidth</b>	16 MHz
<b>Recorder</b>	Disk
<b>DAS Mode</b>	vsop.pro (telescope)

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/fringe-checks/vc010>

## Comments:

Record on /data/xraid. Record on a different disk set compared to that first used for v192a

Connect DAS directly to VSIC

## Observing comments for each antenna:

At Pa

From: <http://www.atnf.csiro.au/vlbi/dokuwiki/> - ATNF VLBI Wiki

Permanent link: <http://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbanov2006/vc010>

Last update: **2015/12/18 16:38**

