

vc010 Setup:

Description	real-time fringe-check for v192a
Antennas	At-Pa
Start	317 19:15:00
Stop	317 20:20:00
PI	LBA fringe-check
Channel 1	DAS #1 IFP#1-L0 1384 - 1400 MHz USB RCP
Channel 2	DAS #1 IFP#1-HI 1400 - 1416 MHz USB RCP
Channel 3	DAS #1 IFP#2-L0 1384 - 1400 MHz USB LCP
Channel 4	DAS #1 IFP#2-HI 1400 - 1416 MHz USB LCP
Channel 5	DAS #2 IFP#1-L0 1416 - 1432 MHz USB RCP
Channel 6	DAS #2 IFP#1-HI 1432 - 1448 MHz USB RCP
Channel 7	DAS #2 IFP#2-L0 1416 - 1432 MHz USB LCP
Channel 8	DAS #2 IFP#2-HI 1432 - 1448 MHz USB LCP
DAS 1 Skyfreq	1400.00
DAS 2 Skyfreq	1432.00
Bandwidth	16 MHz
Recorder	Disk
DAS Mode	vsop.pro (telescope)

Ftp: <ftp://ftp.atnf.csiro.au/pub/people/vlbi/fringe-checks/vc010>

Comments:

Record on /data/xraid. Record on a different disk set compared to that first used for v192a

Connect DAS directly to VSIC

Observing comments for each antenna:

At Pa

From:

<https://www.atnf.csiro.au/vlbi/dokuwiki/> - **ATNF VLBI Wiki**

Permanent link:

<https://www.atnf.csiro.au/vlbi/dokuwiki/doku.php/lbaops/lbanov2006/vc010>

Last update: **2015/12/18 16:38**

